

DESCRIPTION

An alert tells you via text and/or email that a **trailer has started to move**. Alerts are quick, short-term notices you can set up for one trailer. An alert can go to **any mobile number or email address you specify**. Alerts are completely stand-alone. They don't require a landmark. They do require a trailer that's stationary—you can't set an alert for a moving trailer.

Quick Look - How to

- Go to trailer list.
- Highlight a single trailer.
- In the bottom right corner of Trailer Details, choose "Alert Setup" from the menu.
- Choose a movement radius that meets your needs, from ¼ mile to 5 miles.
- Choose a start and end date and recipient list that meets your needs.
- SAVE!

FEATURES	REAL-LIFE BENEFITS
Quick set-up for one trailer, rather than the entire fleet.	Lock down a particular trailer ASAP. Track unauthorized moves.
Set up for one event only: trailer movement out of the alert radius.	Monitor time-sensitive and high-value freight to prevent theft or missing a delivery window.
The alert can go via text or email to ANYONE.	Automatically alert your customer that their time-sensitive freight is on the move.
No landmark is required.	Automated notice requires no pre-work, no sharing of fleet movement.
Alerts expire automatically, which prevents unnecessary notices.	Don't need to cancel; the system works for you.



(A) ALERTS

In the bottom right corner of Trailer Details, choose "Alert Setup" from the menu.



